



NSV

CODICE	MODELLO	LT	A	H	H1
DEXNSV0300	NSV	300	70	97	147
DEXNSV0500	NSV	500	70	148	198
DEXNSV1000	NSV	1000	92	173	223

CODICE	MODELLO	LT	A	B	H	H1
DEXSTT0500	SOTTOSCALA	500	70	130	80	130



SOTTOSCALA



SQR

CODICE	MODELLO	LT	A	B	H	H1
DEXSQR1000	SQR	1000	80	141	125	170

CODICE	MODELLO	LT	A	B	H	H1
DEXSQN0300	SQN3	300	65	67	93	143
DEXSQN0500	SQN3	500	68	87	116	166

SQN3



SQ

CODICE	MODELLO	LT	A	B	H	H1
DEXSQN1000	SQ	1000	68	144	125	175